



What's in the box?

In addition to this guide, the package includes the following items:




**DL-101-E or
DL-101-E-W**



IP67 RJ45



IP67 Power



Quick Start

DL-101-E/DL-101-E-W Getting Started/User Manual

- DL-101-E/DL-101-E-W User Manual

<http://ftp.icpdas.com.tw/pub/cd/usbcd/napdos/IIoT/DL-100/DL-100-E/Document/>

- DL300_utility

http://ftp.icpdas.com.tw/pub/cd/usbcd/napdos/IIoT/utility/dl300_utility/

- DL-101-E/DL-101-E-W Website

http://www.icpdas.com/root/product/solutions/remote_io/rs-485/dl_series/dl-100-e.html



If there is any other question, please feel free to contact us.

Email: service@icpdas.com

產品內容

除了本『快速安裝指南』外，此產品內容還包括以下這些配件：




DL-101-E or
DL-101-E-W



IP67 RJ45



IP67 Power



快速上手指南

DL-101-E/DL-101-E-W 快速入門指南/使用手冊

- DL-101-E/DL-101-E-W 使用手冊

<http://ftp.icpdas.com.tw/pub/cd/usbcd/napdos/IIoT/DL-100/DL-100-E/Document/>

- DL300_utility

http://ftp.icpdas.com.tw/pub/cd/usbcd/napdos/IIoT/utility/dl300_utility/

- DL-101-E/DL-101-E-W 網站

http://www.icpdas.com/root/product/solutions/remote_io/rs-485/dl_series/dl-100-e.html



如果有任何問題，歡迎與我們連繫。

客服信箱：service@icpdas.com